

# SPARE PARTS LIST

POS.	PART NO.	DESCRIPTION
1.	6112	Gun housing A
2.	6111	Gun housing B
3.	6113	Coil (110V, 60Hz)
3.	6113-220	Coil (220V, 50Hz)
4.	6114	Trigger Switch
5.	6115	Armature
6.	6116	Electric Cord
7.	6117	Armature Spring
8.	6118	Volume Control Knob
9.	6119	Volume Control Spring
10.	6120	Bolt A
11.	6121	Bolt B
12.	6122-A/B	Gun unit locking screw
13.	6123	Pump cylinder
14.	6124	Piston
15.	6125	Piston spring
16.	6125	Stator
17-19.	6127-28-29	Valve complete
20.	6130	Container
21.	6131	Suction pipe
22.	6132	Pump unit locking screw
23.	6133	Terminal block
24.	EX400	Adjustable nozzle complete
Optional Accessories		
	5001	Albatross Gun Reel
	6108	Air Dryer Attachment
	6109	Direct feed Attachment

